

YAMAHA AX-700U

Natural Sound Stereo Integrated Amplifier

110W + 110W (8Ω) RMS Output Power, 0.005% THD, 20Hz~20kHz

CD DIRECT for High Quality CD Sound

Reinforced Low Impedance Drivability

CENTER

OWNER'S MANUAL

Thank you for purchasing the YAMAHA AX-700U integrated stereo amplifier.

CONTENTS

CAUTION	2
CONNECTION DIAGRAM	4
CONNECTIONS	5
FRONT PANEL DESCRIPTION	6
OPERATIONS	8
TROUBLESHOOTING	9
SPECIFICATIONS	10

IMPORTANT

Please record the serial number of your unit in the space below.

Model AX-700U

Serial no.


The serial number is located on the rear of the unit.

Retain this Owner's Manual in a safe place for future reference.

WARNING

To prevent fire or shock hazard, do not expose this appliance to rain or moisture.

AX-700U



● Explanation of graphical Symbols



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert you to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

SAFETY INSTRUCTIONS

1 Read Instructions — All the safety and operating instructions should be read before the appliance is operated.

2 Retain Instructions — The safety and operating instructions should be retained for future reference.

3 Heed Warnings — All warnings on the appliance and in the operating instructions should be adhered to.

4 Follow Instructions — All operating and other instructions should be followed.

5 Water and Moisture — The appliance should not be used near water — for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, etc.

6 Carts and Stands — The appliance should be used only with a cart or stand that is recommended by the manufacturer.

7 Wall or Ceiling Mounting — The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.

8 Ventilation — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.

9 Heat — The appliance should be situated away from heat sources such as radiators, stoves, or other appliances that produce heat.

10 Power Sources — The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.

11 Power-Cord Protection — Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

12 Cleaning — The appliance should be cleaned only as recommended by the manufacturer.

13 Nonuse Periods — The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.

14 Object and Liquid Entry — Care should be taken so that objects do not fall into and liquids not spilled into the inside of the appliance.

15 Damage Requiring Service — The appliance should be serviced by qualified service personnel when:

- A. The power-supply cord or the plug has been damaged; or
- B. Objects have fallen, or liquid has been spilled into the appliance; or
- C. The appliance has been exposed to rain; or
- D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
- E. The appliance has been dropped, or the cabinet damaged.

16 Servicing — The user should not attempt to service the appliance beyond those means described in the operating instructions. All other servicing should be referred to qualified service personnel.

17 Grounding or Polarization — The precautions that should be taken so that the grounding or polarization of an appliance is not defeated.

PLEASE NOTE

● CLEANING

Wipe off dust with a soft dry cloth. For heavier dirt use a soft damp cloth then dry immediately with a clean cloth. Do not use harsh cloths, alcohol or other chemical solvents as these products may damage the finish.

● HANDLING

Do not use force when using the switches and knobs. When removing the power plug from the wall outlet always pull directly on the plug, never yank the cord. Before moving your amplifier be sure to unplug the power cord and remove all other connecting cables.

● CONVENIENCE OUTLETS

Do not connect audio equipment to the AC outlets on the rear panel if that equipment requires more power than the outlets are rated to provide.

IN CASE OF TROUBLE

● TROUBLESHOOTING


Consult the Troubleshooting Chart for advice on the common operating errors before concluding that your unit is faulty.

● SERVICING

Do not open the cabinet or attempt to make repairs by yourself as this may result in damage to the set or electrical shock to yourself. Refer any servicing to your Yamaha dealer.

CONNECTION DIAGRAM

- Before making any connections turn off all equipment.
Be sure to connect the left (L) and right (R) channels consistently between components.




CONNECTIONS


● CONNECTING THE SPEAKERS

Connect the cords for the left speakers to the L terminals and the right speaker cords to the R terminals, ensuring that the polarity (+ and -) markings are observed. Be sure to do this consistently from component to component. If the polarity is reversed at either speaker the sound will be unnatural and lack bass. Speaker cords should be cut as short as possible. Avoid coiling the wire on the floor or bundling it up with cords from other system components. The AX-700U speaker terminals allow for two connection methods. The first method outlined usually provides a more secure connection.

1. Strip about 1cm (0.39in) of insulating material from the ends of the speaker wires and twist the strands of each end. Loosen the speaker terminal knobs, insert the exposed wire into the hole and then tighten the speaker terminal knobs.



2. Banana Chip connections are also possible. Simply insert the Banana Chip connector into the corresponding terminal.



● CONNECTING A TURNTABLE

Connect the output cords of the turntable to the PHONO jacks and connect the ground wire to the GND terminal. Normally, connecting the ground wire produces minimum hum but in some cases better results are obtained with the ground wire disconnected. The turntable component and its output cords should be positioned well away from sources of hum such as power cords or power transformers of other system components.

● CONNECTING A TUNER

Connect the cords from the tuner's output jacks to the TUNER jacks of the amplifier. Position the tuner so that its AM antenna is well away from the amplifier for the best possible reception.

● CONNECTING TO THE CD AND VIDEO/AUX JACKS

Connect your CD component to the CD terminals and the sound output leads of your video component to the VIDEO/AUX terminals. Please note that a turntable cannot be connected to these

jacks as they do not provide the necessary RIAA equalization.

● CONNECTING TAPE DECKS

TAPE DECK 1.

Connect the cords from the tape deck's Line In jacks to the REC OUT jacks of TAPE 1, ensuring that left and right are not reversed. Then connect the cords from the tape deck's Line Out jacks to the TAPE 1 PB jacks.

TAPE DECK 2 and DAT can be connected in similar fashion to the TAPE 2 and DAT terminals.


● AC OUTLETS

For added convenience the AX-700U provides 3 AC outlets. Two "switched" outlets (the power to these receptacles is turned on and off by this unit's power switch) and one "unswitched" outlet (the power to this receptacle is independent of this unit's power switch). Be sure not to connect appliances totaling more than 200 watts to the unswitched outlet or more than 100 watts to the two switched outlets.

● ACCESSORY

The Accessory option allows you to connect a signal processing system, such as an equalizer, in the signal path prior to the Tone control. Connect the ACCESSORY SEND jacks to the inputs of the equalizer and the ACCESSORY RECEIVE jacks to the outputs of the equalizer.

FRONT PANEL DESCRIPTIONS



① POWER SWITCH (POWER)

Press once to turn the power ON and once again to turn the power OFF. Before turning the power ON set the volume to its lowest position (extreme counterclockwise), to protect the speakers from any sudden high level sound.

② POWER INDICATOR

Lights when power is ON.

③ SPEAKER SWITCHES (SPEAKERS)

As one or two speaker systems can be connected to the AX-700U, these switches allow you to select speaker system A, B or both at once. When listening to the headphones only, press both the A and B switches to the OFF position.

④ TONE BYPASS CONTROL SWITCH (TONE BYPASS)

Depress this switch to channel the input signal directly to the output stage of your amplifier, bypassing the Bass, and Treble controls therefore avoiding any "muddying" caused by switch and circuit routing to provide a pure sound. Use this switch to compare tone control settings with the "flat" amplifier sound.

⑤ INPUT SELECTOR KEYS

Selects the program source you wish to listen to. The indicator LED above the selected source will light up.

⑥ CD DIRECT SWITCH (CD DIRECT)

This switch allows you to route the CD input signal directly to the output stage bypassing the Input Selector, Accessory, Muting, Mode, Loudness, and Balance controls therefore avoiding any "muddying" caused by switch and circuit routing to provide a pure sound.

⑦ MUTING SWITCH (MUTING)

This control allows you to lower the volume temporarily without disturbing the original setting. Pressing the switch lowers the volume by 20db and lights the LED indicator, pressing again restores the normal volume setting.

⑧ VOLUME CONTROL KNOB (VOLUME)

This controls the sound level. Turning clockwise increases the sound volume and turning counterclockwise decreases it. Set this knob to the minimum level before turning the power ON or using the Input Selector Keys to select a different sound source, therefore protecting the speakers from any sudden high level sound.

⑨ REC OUT SELECTOR (REC OUT)

This switch selects the source to be channelled to the rear panel REC OUT terminals independent of the Input Selectors and permits tape copying from TAPE 1 to 2/DAT or DAT to TAPE 1/2.

⑩ PHONO SELECTOR SWITCH (PHONO)

Selects either MM (moving magnet) or MC (moving coil) position to match your cartridge.

⑪ MODE SWITCH (MODE)

Permits switching between stereo and mono operation. Normally this switch should be set to the stereo position.

⑫ SUBSONIC FILTER CONTROL SWITCH (SUBSONIC)

This switch cuts out ultra low frequency signals caused by turntable rumble or warped records, yet retains sound quality.

⑬ LOUDNESS CONTROL KNOB (LOUDNESS)

This control provides compensation for the human ear's loss of sensitivity to high and low frequency ranges at low volumes. As the amount of the compensation required is determined by the listening level, this control provides the most accurate compensation for any listening level. Set it to the flat position while the volume control is set to your normal listening level. Turning it counterclockwise will decrease the volume while retaining the natural balance of low and high frequencies.

⑭ BALANCE CONTROL KNOB (BALANCE)

This knob is used to adjust the relative volume of the left and right channels, enabling you to compensate for unbalance created by installation locations of the speakers.

⑮ TREBLE CONTROL KNOB (TREBLE)


This knob controls treble response. Turn it clockwise to boost or counterclockwise to attenuate treble response. When this knob is in the center defeat position a flat response is obtained.

⑯ BASS CONTROL KNOB (BASS)

This knob controls bass response. Turn it clockwise to boost or counterclockwise to attenuate bass response. When this knob is in the center defeat position a flat response is obtained.

⑰ HEADPHONES JACK (PHONES)

Stereo headphones with a standard plug can be connected to this jack.



AX-700U

OPERATIONS

● Normal listening operation

1. Turn the volume control to the minimum level before turning the power ON. The power indicator lights when power is ON.
2. Using the SPEAKERS switches select the desired speaker system(s) or leave both switches in the OFF position to use the headphones.
3. Select the desired program source using the Input Selector Keys. The corresponding input indicator lights up.
4. Activate your chosen component.
5. Adjust your VOLUME, LOUDNESS, BASS, TREBLE and BALANCE to provide the desired sound quality.

● To record from a sound source

1. Using the REC OUT selector select the source to be recorded.
2. Activate your chosen source component.
3. To monitor the sound being played via the speakers or headphones use the Input Selector Keys to select the source program, (noting the procedures outlined above in Normal listening operation).
4. To start recording set the receiving tape deck(s) to record. If your tape deck has three head monitoring capability you can monitor the just recorded signal by selecting the corresponding tape deck switch on the Input Selector Keys.
5. To listen to an alternate sound source merely select the desired component using the Input Selector Keys, (noting the procedures outlined above in Normal listening operation).







● Tape dubbing

Three tape decks can be connected to the AX-700U and tape dubbing can be performed from TAPE 1 to 2/DAT or DAT to TAPE 1/2.

1. Set the REC OUT selector to the TAPE COPY position (1 ► 2/DAT or DAT ► TAPE 1/2).
2. To start recording set the source tape deck to playback and the receiving deck to record.
3. To monitor the source sound, use the Input Selector Keys to select the source deck. If your recording tape deck has three head monitoring capability, you can monitor the just recorded signal by selecting the receiving deck on the Input Selector Keys.

4. To listen to an alternate sound simply select the desired input component via the Input Selector Keys. (Noting the procedures outlined above in Normal listening operation) This has no adverse effects on the dubbing quality.

Independent Recording and Listening Examples.

ACTION	INPUT SELECTOR	REC OUT
Listening to a record via the speakers while recording an AM/FM broadcast.		
Listening to a CD while recording it.		
Listening to an AM/FM broadcast while "dubbing" a tape from Tape 1 to 2.		

TROUBLESHOOTING

Before assuming that your unit is faulty, please check the following troubleshooting list which details the corrective action you can take yourself without having to call a service engineer. If you have any doubts or questions, contact your nearest Yamaha dealer.

PROBLEM	CAUSE	REMEDY
Power is not supplied even though the Power switch is turned on .	The power plug is not securely plugged in.	Plug it in securely.
There is no sound with any input selector switches pressed.	The Speakers switch is not set correctly.	Set the Speakers switch correctly.
	The input cords are not connected securely.	Connect them securely.
	The speaker system is not connected correctly.	Check and secure connections.
Only CD output is possible	The CD DIRECT switch is ON.	Push the CD DIRECT switch to the OFF position.
There is no sound from one speaker.	The speaker connections are not secure.	Secure the connections.
	The Balance control is set all the way to the left or right.	Adjust the Balance control correctly.
There is a lack of bass and no ambience.	The + and - cords have been reversed at the amp or speakers.	Connect the speaker wires in the correct phase (+ and -).
There is a humming sound when playing records.	The input cords are not connected securely.	Plug the input cords in securely.
	The turntable's ground wire is not connected.	Connect the ground wire.
There is a howling sound when playing records at high volume.	The turntable and the speakers are too close together or the turntable is not mounted on a firm surface.	Change the location of the turntable or the speakers.
Turning the Bass or Treble knob does not affect the tone.	The Tone Bypass switch is on.	The Tone Bypass switch must be turned off to use the controls.
The sound suddenly goes off.	Driving speakers outside the rated impedance range at high power for an extended period has activated the speaker protection circuit.	Turning the AX-700U off and then on will reset the speaker protection circuit. Use speakers inside the rated impedance range.
	There is a malfunction in the amplifier.	Consult your Yamaha dealer.

AX-700U

SPECIFICATIONS

Minimum RMS Output Power Per Channel	
20Hz ~ 20KHz 0.005% THD 8Ω	110W
0.008% THD 6Ω	130W
Dynamic Power Per Channel (by IHF Dynamic Headroom measuring method)	
8Ω/6Ω/4Ω	160W/210W/280W
Power Bandwidth	
0.03% THD 55W 8Ω	10Hz ~ 50KHz
Damping Factor	
1KHz 8Ω	100
Input Sensitivity/Impedance	
Phono MC	160μV/220Ω
MM	2.5mV/47kΩ
CD/VIDEO-AUX/TUNER/TAPE	150mV/47kΩ
Input Sensitivity (New IHF)	
Phono MC	16μV
MM	0.25mV
CD/VIDEO-AUX/TUNER/TAPE	15mV
Maximum Input Signal 1KHz	
0.01% THD Phono MC	10mV
MM	160mV
Output Level/Impedance	
Rec Out	150mV/470Ω
Headphone Jack Rated Output/Impedance	
0.005% THD RL = 8Ω	0.85V/8Ω
Frequency Response	
CD/VIDEO-AUX/TUNER/TAPE	20Hz ~ 20kHz +0, -0.5dB
RIAA Equalization Deviation	
Phono MC 20Hz ~ 20KHz	±0.3dB
MM 20Hz ~ 20KHz	±0.2dB
20Hz ~ 100KHz	±0.5dB
Total Harmonic Distortion 20Hz ~ 20KHz	
Phono MC to REC OUT, 3V	0.006%
MM to REC OUT, 3V	0.003%
CD/VIDEO-AUX/TUNER/TAPE to Sp Out 55W/8Ω	0.005%
Intermodulation Distortion	
CD/VIDEO-AUX/TUNER/TAPE	
Rated Output/8Ω	0.002%
1W/8Ω	0.003%

Signal to Noise Ratio (IHF-A-Network)	
Phono MC (500μV Input Shorted)	76dB
MM (5mV Input Shorted)	92dB
CD/VIDEO-AUX/TUNER/TAPE (Shorted)	106dB
Signal to Noise Ratio (New IHF)	
Phono MC	75dB
MM	75dB
CD/VIDEO-AUX/TUNER/TAPE	86dB
Residual Noise (IHF-A-Network) TONE BYPASS ON	
	150μV
Channel Separation Vol - 30dB	
Phono MC/MM Input Shorted 1KHz	70dB
CD/VIDEO-AUX/TUNER/TAPE input 5.1kΩ terminated 1KHz	65dB
Tone Control Characteristics	
BASS boost/cut	±10dB at 20Hz
turnover frequency	350Hz
TREBLE boost/cut	±10dB at 20KHz
turnover frequency	3.5KHz
Filter Characteristics	
Subsonic	15Hz/12dB/oct
Continuous Loudness Control (Level Related Equalization)	
Attenuation	-40dB(1KHz)
Audio Muting	-20dB
Power Supply	
	AC120V 60Hz
Power Consumption	
	450W
AC Outlet	
Switched x 2	100W max.
Unswitched x 1	200W max.
Dimensions (W x H x D)	
	435 x 165 x 416mm
	(17.1 x 6.5 x 16.4 in)
Weight	
	11.5Kg
	(25.4lbs)

* Specifications subject to change without notice.

— MEMO —

A series of 20 horizontal dotted lines for writing.

SINCE 1887  **YAMAHA**
NIPPON GAKKI CO., LTD. HAMAMATSU, JAPAN

VD09530-0

BWgb, BR  Printed in Japan.